



**AKEL®**

## starter drivers

**ASD - 01**



TYPE : HITACHI  
OEM NO : UH171  
TEETH : 11

**ASD - 02**



TYPE : HITACHI  
OEM NO : BEKO 400  
TEETH : 11

**ASD - 03**



TYPE : NIKKON  
OEM NO : KD1-23500-0010  
TEETH : 11

**ASD - 04**



TYPE : NIKKO  
OEM NO : KD1-23500-0090  
TEETH : 11

**ASD - 05**



TYPE : NIKKO  
OEM NO : KD1-23500-0170  
TEETH : 12

**ASD - 06**



TYPE : NIKKO  
OEM NO : KD1-23500-0190  
TEETH : 13

**ASD - 07**



TYPE : NIKKO  
OEM NO : KD1-23500-0250  
TEETH : 13

**ASD - 08**



TYPE : NIKKO  
OEM NO : KD1-23500-0260  
TEETH : 12

**ASD - 09**



TYPE : NIKKO  
OEM NO : KD0 23500-0422  
TEETH : 11

**ASD - 10**



TYPE : NIKKO  
OEM NO : KD0-23500-0500  
TEETH : 11

**ASD - 11**



TYPE : NIKKO  
OEM NO : KD1-21500-1530  
TEETH : 11

**ASD - 12**



TYPE : NIKKO  
OEM NO : KD1-21500-1600  
TEETH : 11



**AKEL®**

## starter drivers

**ASD - 13**



TYPE : NIKKO  
OEM NO : KD1-21500-1610  
TEETH : 13

**ASD - 14**



TYPE : NIKKO  
OEM NO : KD1-21500-1750  
TEETH : 11

**ASD - 15**



TYPE : NIKKO  
OEM NO : KD1 23500-0110  
TEETH : 11

**ASD - 16**



TYPE : NIKKO  
OEM NO : BOBCAT  
TEETH : 12

**ASD - 17**



TYPE : MITSUBISHI  
OEM NO : 4Y-973  
TEETH : 15

**ASD - 18**



TYPE : MITSUBISHI  
OEM NO : M191T66171  
TEETH : 11

**ASD - 19**



TYPE : MITSUBISHI  
OEM NO : ÇUKUROVA  
TEETH :

**ASD - 20**



TYPE : MITSUBISHI  
OEM NO : M357T73571  
TEETH : 11

**ASD - 21**



TYPE : MITSUBISHI  
OEM NO : M191T65171  
TEETH : 13

**ASD - 22**



TYPE : MITSUBISHI  
OEM NO : M191T72571  
TEETH : 13

**ASD - 23**



TYPE : NIPPONDENSO  
OEM NO : 28011-1260  
TEETH : 11

**ASD - 24**



TYPE : NIPPONDENSO  
OEM NO : 028300-3693  
TEETH : 10



**AKEL®**

## starter drivers

**ASD - 25**



TYPE : SAWAFUJI  
OEM NO : SD 1361-004-10  
TEETH : 11

**ASD - 26**



TYPE : SAWAFUJI  
OEM NO : SD 1361-049-00  
TEETH : 11

**ASD - 27**



TYPE : SAWAFUJI  
OEM NO : SD 1361-047-00  
TEETH : 11

**ASD - 28**



TYPE : SAWAFUJI  
OEM NO : SD 1361-048-00  
TEETH : 12

**ASD - 29**



TYPE : SAWAFUJI  
OEM NO : KAWASAKI  
TEETH : 11

**ASD - 30**



TYPE : SAWAFUJI  
OEM NO : KAWASAKI  
TEETH : 11

**ASD - 31**



TYPE : SAWAFUJI  
OEM NO : SD 1361-058-00  
TEETH : 12

**ASD - 32**



TYPE : DELCO  
OEM NO : 1986244  
TEETH : 10

**ASD - 33**



TYPE : DELCO  
OEM NO : 1985262  
TEETH : 12

**ASD - 34**



TYPE : DELCO  
OEM NO : 6N-3826  
TEETH : 11

**ASD - 35**



TYPE : DELCO  
OEM NO : 6N3827  
TEETH : 12

**ASD - 36**



TYPE : BOSCH  
OEM NO : 7F-4537  
TEETH : 11



**AKEL®**

## starter drivers

**ASD - 37**



TYPE : BOSCH-CATERPILLAR  
OEM NO : 3T-8672  
TEETH : 12

**ASD - 38**



TYPE : YANMAR  
OEM NO : YM 129900-77510  
TEETH : 11

**ASD - 39**



TYPE : MITSUBISHI  
OEM NO : M605X98871  
TEETH : 11

**ASD - 40**



TYPE : NIKKO  
OEM NO : KD1 21500-1580  
TEETH : 13

**ASD - 41**



TYPE : NIKKO-MITSUBISHI  
OEM NO : KD0 23500-0690  
TEETH : 15

**ASD - 42**



TYPE : NIKKO  
OEM NO : KD0 23500-0390  
TEETH : 11

**ASD - 43**



TYPE : NIKKO-HITACHI  
OEM NO : 8980171360  
TEETH : 13T 4HK1

**ASD - 44**



TYPE : MITSUBISHI  
OEM NO : M191X60171  
TEETH : 11T 6HK1

**ASD - 45**



TYPE : MITSUBISHI HITACHI  
OEM NO : 670  
TEETH : 11T

**ASD - 46**



TYPE : MITSUBISHI -DAEWOO  
OEM NO : 65.26201.7049  
TEETH : 11T

**ASD - 47**



TYPE : DELCO-CAT  
OEM NO : 184-6964  
TEETH : 13